DANDY CURB SACK® CURB AND GUTTER INLET PROTECTION SYSTEM GUIDE SPECIFICATION

PRODUCT:

DANDY CURB SACK®

MANUFACTURER:

Dandy Products Inc. P.O. Box 1680 Powell, Ohio 43065

Phone: 800-591-2284 Fax: 740-881-2791

Email: sdunnpe@dandyproducts.com
Web: www.dandyproducts.com

1.0 **Description:**

1.1 Work covered under this item consists of installing a Dandy Curb Sack® curb and gutter inlet protection system. The purpose is to keep silt, sediment, and construction debris out of the storm water system.

2.0 Material:

- 2.1 The Dandy Curb Sack® curb and gutter inlet protection unit shall be a sewn geotextile fabric unit **made in the U.S.A.** enclosing a porous structure in the form of a cylindrical tub placed in front and extending beyond the inlet opening on both sides and have a geotextile fabric sack attached designed to fit the opening of the catch basin or drop inlet and to hang underneath the grate and into the catch basin.
- 2.2 The Dandy Curb Sack® shall have lifting straps to allow removal of the unit and manual inspection of the storm water system.
- 2.3 The Dandy Curb Sack® unit shall utilize an orange monofilament fabric that is manufactured in the U.S.A with the following characteristics:

PROPERTY	TEST METHOD	UNITS	TEST RESULTS	
Tensile Strength	ASTM D4632	lbs	450 x 300	
Elongation	ASTM D4632	%	38% x 21%	
Trapezoidal Tear	ASTM D4533	lbs	165 x 150	
CBR Puncture	ASTM D6241	lbs	1000	
HYDRAULIC PROPERTIES:				
Apparent Opening Size (AOS)	ASTM D 4751	US Std Sieve	30	
Permittivity	ASTM D 4491	sec ¹	4.9	
Water Flow Rate	ASTM 4491	gal/min/ft ²	365	
% Open Area (POA)	COE - 22125-86	%	29	

UV Resistance	ASTM D 4355	%	70
(% Retained @ 2500 hrs)			
Color			Orange ¹

¹The color orange is a trademark of Dandy Products, Inc.

3.0 Installation:

- 3.1 Remove the grate from the catch basin.
- 3.2 For Oil and Sediment Model; to install or replace absorbent, place absorbent pillow in unit, on the bottom (below-grade side) of the unit.
- 3.3 Stand the grate on end. Move the top lifting straps out of the way and place the grate into the Dandy Curb Sack® unit so that the grate is below the top straps and above the lower straps. The grate should be cradled between the upper and lower straps.
- 3.4 Holding the lifting devices, insert the grate into the inlet, then lower back edge with cylindrical tube into place, being careful that the grate remains in place and being careful not to damage the Dandy Curb Sack® unit. The cylindrical tube should partially block the curb hood opening when installed properly.

4.0 Maintenance:

- 4.1 Remove all accumulated sediment and debris from vicinity of unit after each storm event.
- 4.2 After each storm event and at regular intervals, look into the Dandy Curb Sack® unit. If the unit is more than 1/3 full of accumulated sediment, the unit must be emptied.
- 4.3 To empty the unit, using the lifting straps lift the unit out of the inlet and remove the grate. Transport the unit to an appropriate location for removal of the contents. Holding the dumping straps on the outside at the bottom of the unit, turn the unit upside down, emptying the contents. Reinstall unit as above.
- 4.4 For Oil and Sediment Model; remove and replace absorbent when near saturation.
- 4.5 Dispose of unit and/or absorbent in accord with applicable Federal, state and local environmental laws and regulations.

5.0 Method of Measurement:

5.1 The quantity to be paid is for the actual number of Dandy Curb Sack® inlet protection units installed

6.0 Basis of payment:

The property values listed above are effective April 2022 and are subject to change without notice.

6.1	The unit price shall include labor, equipment, and materials necessary to complete
	the work and maintain the Dandy Curb Sack® inlet protection units.

6.2 Payment for the completed work will be made at the contract prices fo	6.2	Payment	for the	completed	l work will	be made a	t the contract	t prices f	for:
---	-----	---------	---------	-----------	-------------	-----------	----------------	------------	------

 ITEM
 UNIT
 DESCRIPTION

 Dandy Curb Sack®
 EA
 Inlet Protection Unit (#____Inlet)